



GPS Phone Watch

Model NO.: R12W

User Manual

Version 1.0

CONTENT

1. Product introduction.....	2
2. Appearance and interface.....	2
2.1 Appearance.....	2
2.2 Interfaces and buttons.....	2
3. Device installation.....	3
3.1 Install sim card.....	3
3.2 Buckle installation.....	3
3.3 Device charging.....	3
3.4 Power on/off.....	3
3.5 View SMS.....	3
3.6 View management information.....	3
3.7 Anti-tear and anti-shear.....	4
3.8 Charging.....	4
4. How to use the watch on the APP.....	4
4.1 Install the APP and register user account.....	4
4.2 Register your watch in APP.....	6
4.3 Activate the watch.....	7
5. How do we operate on the platform.....	8
5.1 Device activation.....	8
5.2 Set APN.....	8
5.3 Set IP.....	8
5.4 Equipment management.....	8

1. Product introduction

Available colors: black.

GPS Phone Watch R12W supports GPS, WIFI and LBS positioning, anti-violent disassembly and IP67 waterproofing. It can supervise specific personnel around the clock, improve the supervision efficiency of the staff, and make the management more convenient and humanized.


2. Appearance and interface

2.1 Appearance



R12W GPS TRACKER WATCH FOR ELDERLY

2.2 Interfaces and buttons





MYROPE

ROPE INNOVATION CO., LTD.

CONFIDENTIAL NO.: ROPE-15121802

3. Device installation

3.1 Install sim card

Please open the 4 screws on the bottom cover of the watch and install the SIM card according to the illustration inside the bottom cover. Insert a Nano-SIM card into this watch. Using a non-standard card may damage your watch. If you need to replace or purchase a SIM card, please contact your network operator.

3.2 Buckle installation

Please use the matching opposite screws and screwdrivers in the package to lock the watch buckle.

3.3 Device charging

This device supports two charging methods:

- A. Use the magnetic data cable included in the package to charge the watch.
- B. Please use the power bank included in the package to charge the watch.

3.4 Power on/off

The watch cannot be turned off. When the low battery is reminded, please charge it in time, otherwise, the watch will automatically alarm.

In case of a special situation where the watch is turned off, please press the page up button to turn on.

3.5 View SMS

- A. Press the up and down page keys to view the short message.
- B. The device can set up a communication white list to automatically filter spam messages.

3.6 View management information

While holding down the page up key, press the page down key 3 times in succession, the watch enters the management information interface to view.



3.7 Anti-tear and anti-shear

Do not disassemble the buckle or cut the strap without permission, otherwise the device will automatically alarm.

3.8 Charging

- A. The power of the charging treasure is less than 15%, and the red light flashes.
- B. The power bank is fully charged, and the red light is always on.
- C. When the power bank charges the watch, and the blue light flashes.
- D. The power bank fully charges the watch, and the blue light is always on.
- E. The power of the charging treasure is less than 15% to charge the watch, and the red and blue lights flash at the same time.

4. How to use the watch on the APP

4.1 Install the APP and register user account

Please download the app **Rtrac S** from Google Play or APP Store

For android can download from

<https://play.google.com/store/apps/details?id=com.myrope.rtrac>

For ios can download from

<https://apps.apple.com/us/app/rtrac-s/id1404229080>

Please use the correct number and email address since it will be used for receiving verifying code and recover the password in case you forgot, besides, your call will be rejected by watch if your phone number is wrong.



Rtrac S

Language ▼

Username

Password

Login

[Forget Password](#)

[Register](#)

Register an



Register

Please input your email to complete the register.

Email

Next


Input your email and click next, it will send a valid code to your email

4.2 Register your watch in APP


Register your watch:

Please purchase a SIM card and ensure it has caller ID, SMS, voice communication and GPRS features, please install the SIM card to the slot.

After registered user account, it will auto-redirect the interface to add watch. It's also ok to click the specific button to add a new watch.



To add the watch, please scan the QR code or fill in IMEI which is printed on the watch back.



Please do make sure the SIM card phone number in the watch is correct, otherwise, the watch cannot locate in the map. Please note the country code is not required when you input the phone number of SIM card.

4.3 Activate the watch

After the watch is added on the app, please send two SMS command to activate it.

Please send the second command to set APN information for the watch:

setAPN#APN#USERNAME#PASSWORD#

APN is required, USERNAME and PASSWORD are optional.

For example:

setAPN#cmnet####

Please send the first command to set IP and port for the watch:

\$HX,SSER,OK,{IP},{Port},C,Last 6 digits of IMEI

For example:

\$HX,SSER,OK,47.90.254.117,20017,C,888888

Terminal reply:

\$HX,SSER,OK,E,47.90.254.117,20017,C,860721009888888

After received reply from the watch, please take the watch outside for a while, and it will be located on the APP.



5. How do we operate on the platform

5.1 Device activation

Users can download RtracS through Google play, register and log in via email after installation, edit the SMS sending device after adding the watch as prompted.

5.2 Set APN

setAPN#APN#USERNAME#PASSWORD#

APN is required, USERNAME and PASSWORD are optional.

For example:

setAPN#cmnet####

5.3 Set IP

\$HX,SSER,OK,{IP},{Port},C,Last 6 digits of IMEI

For example:

\$HX,SSER,OK,47.90.254.117,20017,C,888888


Terminal reply:

\$HX,SSER,OK,E,47.90.254.117,20017,C,860721009888888

5.4 Equipment management

Administrator login <https://www.overseetracking.com>

After login, you can configure the device for the selected device.



Set the device upload data interval, the default is 1 hour positioning, it is not recommended to set the interval below 30 seconds.



GPS TRACKING AND TELEMATICS PLATFORM

Welcome jerry!

Tracking Map

Multiple Tracking

Information Management

Reports and Charts

User Profile

Exit

Setting

Alarm

Message

Vehicle Status

GEO-Fence Status

Please enter IMEI/IDName

My Trackers (1/35)

Ungrouped List(1/16)

2020-05-29 18:55:14

0Km/h

Voltage: 0V

R12W ID/IMEI 23000005123860721009169863

Set Interval

Set the data uploading interval for trackers. Notes: You are able to set different intervals when ignition on or off. The default interval is 30s for both ignition on and off.

Interval for Ignition ON:

30

Interval for Ignition OFF:

30

Send

Back

Set the alarm receiving number

GPS TRACKING AND TELEMATICS PLATFORM

Welcome jerry!

Tracking Map

Multiple Tracking

Information Management

Reports and Charts

User Profile

Exit

Setting

Alarm

Message

Vehicle Status

GEO-Fence Status

Please enter IMEI/IDName

My Trackers (2/35)

Ungrouped List(2/16)

2020-6-1 19:23:50

0Km/h

Voltage: 0V

R12W ID/IMEI 23000005123860721009169863

Set Alert Phone Number

The alert phone number is for receiving alarms from tracker. Notes: If you want to remove the alert phone number, please leave the blank empty.

Phone number 1:

Phone number 2:

Phone number 3:

Send

Back

Send text message to watch

GPS TRACKING AND TELEMATICS PLATFORM

Welcome jerry!

Tracking Map

Multiple Tracking

Information Management

Reports and Charts

User Profile

Exit

Setting

Alarm

Message

Vehicle Status

GEO-Fence Status

Please enter IMEI/IDName

My Trackers (2/35)

Ungrouped List(2/16)

2020-6-1 19:23:50

0Km/h

Voltage: 0V

R12W ID/IMEI 23000005123860721009169863

Send Message to Handset

Send the message from system to the handset that has been attached with supported tracker.

Message Content:

Send

Back